## BOND BREAKER TAPE (25mm MIN.) ARDEX BUTYNOL (adhered with ARDEX WA 98 ADHESIVE)

## TYPICAL PLYWOOD SUBSTRATE JOINS DETAIL

## NOTES

All plywood substrate joins must be taped to prevent stressing of ARDEX BUTYNOL due to substrate movement.



The technical details, recommendations & other information contained in this drawing is given in good faith & represents the best of our knowledge and experience at the time of design. It is your responsibility to ensure that our products are used used correctly in accordance with any applicable Australian Standard, our instructions & recommendations are only for the uses they are intended. We also reserve the right to update information without prior notice to reflect our ongoing research and development program. Country specific recommendations, depending on local standards, codes of practice, building regulations and industry guidelines may effect specific installation recommendations. The supply of our products and services are also subject to certain terms, warranties & exclusions which are available to you on request

FILE NAME	TYPICAL PLYWOOD SUBSTRATE JOINS DETAIL	ARDEX AUSTRALIA
DRAWN	15/03/2024 by AD	www.ardexaustralia.com
CHECKED	ADAM MCGLONE	SCALE NTS
SIZE	A4	DRAWING D87